



How to read the relative illumination chart

The horizontal axis shows the image height (the distance from the center to the edge of the image [mm]).

The vertical axis shows the amount of light in the image (based on the amount of light in the image center being 100%). If the peripheral amount of light is lower than the center, the four corners of image will be darker (vignetting).



Wide



Tele